Store Supply Warehouse Economy Gondola End Cap Assembly Instructions

- 1- Remove cap from the bottom of the UPRIGHT STANDARDS and insert a BASE FOOT into each of the UPRIGHT STANDARDS. Replace bottom cap.
- 2- Attach the BASE KICKPLATE into the slots in each BASE FOOT.
- 3- Lower the BASE SHELF in place by lining up the edge of the shelf with the grooves in the BASE FOOT.
- 4- Insert the 7" PEGBOARD BACKER into the slots on the inner bottom of the UPRIGHT STANDARDS. Repeat this process for each of the 12" PEBOARD BACKERS.
- 5- Place the METAL TOP SPANNER in place on top of the unit to complete the installation.

